

## **Recommended Tools for an Over-the-Range Microwave Installation**

- Drill bit for both wood and tile
- Hole saw
- Washers
- Lag bolts
- Wood fill-in spacers
- Tin snips
- Phillips and flathead screwdrivers
- Vacuum
- Safety glasses
- Torpedo level
- Stud finder
- Measuring tape
- Luan underlayment
- Shims
- 3mm HVAC foil tape
- Tarps/Blankets for covering countertops
- Scuff shield
- Shoe covers
- Dolly or moving strap